

<head>

MONSTER

CleanView™ 4 and CleanView™ 2

Clean Look On-Wall Cable Management System

User Guide & Warranty Information

<head>

CleanView Features

<bullets>

Monster Exclusive Custom-Fit Cable Tracks and Covers

Monster Exclusive Internal Channels

Monster Exclusive Color-Coded Clips

Monster Exclusive Recessed Flush Mounting

Monster Exclusive Interlocking Tracks

Attaches To Wall Two Ways

Paint-Ready Surface Can Match Any Decor

<head>

Table of Contents:

<contents...>

Thank You Message

CleanView Kit Includes

Planning Wall Layout

Cutting The Track Base Pieces

Attaching To Wall

Placing Cables Inside

Snap On Covers and Joiner/End Pieces

Cutting The Covers

Care & Maintenance

THANK YOU for purchasing Monster® CleanView™ Cable Management System. CleanView provides many of the aesthetic benefits of "built-in" in-wall wiring, without the expense, hassle and electrical concerns of in-wall wiring. Unlike other wall cable covers, Monster CleanView includes many unique, exclusive features to ensure a professional looking installation every time. These include our recessed adhesive for absolutely flush mounting, and covers that hide rough edges on pieces that you cut. Plus, our special paint-ready surface will blend in with practically any wall. Please read these instructions thoroughly before you get started, to ensure a perfect installation.

<head>
MONSTER
CleanView™ 4 and CleanView™ 2
Clean Look On-Wall Cable Management System

Kit Includes:

- <bullets>
- 4 16" (40.6 cm) Cable Tracks and Covers
 - 1 90° Right Angle Connector Track and Cover
 - 20 Color-Coded Clips
 - 2 Joiner/End Covers
 - Mounting Screws
 - Instructions

<head>

Planning Wall Layout

<body>

Monster CleanView Cable Management System is designed to look fantastic with fast, easy installation. Careful planning of your cable layout is essential. Double-check measurements!

<bullets>

Using a pencil, mark the wall along the centerline of the planned layout.

Note: For best results, use a level to draw horizontal and vertical lines on wall.

Measure the length(s) of Straight pieces needed in your layout to determine if any piece(s) will need to be cut. (Note: If you use the Corner section, remember to subtract its length.)

<head>

Cutting The Track Base Pieces

<body>

Monster CleanView Cable Management System can be easily cut using a utility knife or strong scissors.

<bullets>

First assemble the track pieces into the desired layout. Set the covers aside, and slide the base pieces together, making sure they interlock.

Use a pencil to mark the track piece(s) at the desired length.

Cut the base pieces using a utility knife or strong scissors. Do NOT cut the cover pieces at this time!

Note: Cut edges will no longer interlock with other pieces. Only the last, end piece in a run should be cut!

<head>

Attaching To Wall

<body>

Monster CleanView Cable Management System can be attached to the wall two ways—using peel off adhesive, or screws. Adhesive does not require holes in the wall, while screw mounting is more permanent.

<bullets>

First assemble the complete track base to ensure proper fit.

Have someone assist you in holding the base pieces against the wall.

<sub-head>

To Attach with Peel-Off Adhesive

<bullets>

Starting at the top of your layout, remove peel-off tape in back of the first track base piece.

Hold the first piece over the wall (but not touching) in the desired location.

Bring one end in contact with the wall, press it down, and gradually smooth down the entire piece against wall.

Apply pressure for several seconds for maximum adhesion.

Carefully place the next piece below, and continue the layout.

Line up interlock pins in base of Corner section with holes in Straight pieces before pressing against wall.

<sub-head>

To Attach with Mounting Screws

<bullets>

Mark the wall with the locations of mounting holes inside the base pieces.

Use the drywall screws provided for most ordinary walls. (Note: Wall anchors, masonry screws, or other special mounting hardware may be substituted where necessary.)

Starting at the top of your layout, attach first piece.

Place the next piece below, and continue the layout.

Line up interlock pins in base of Corner section with holes in Straight pieces before attaching to wall.

<head>

Placing Cables Inside

<body>

Monster CleanView™ Cable Management System is available in versions for 2-cable and 4-cable wiring. If you need to run more than 2 cables, be sure you have the 4-cable version. Each cable should have its own "channel", or slot, within the track base pieces.

<bullets>

Be sure all cables are long enough—before you start.

Start with the AC power cord. One "channel," or cable path, is wider—this is for AC power. Run the AC power cord inside this channel.

Place cable clips over AC power cord to hold in place. Place clips at end points of cable run, and at several intermediate points.

Now, run the other cables (video, audio, Ethernet, etc.) inside the other channel(s).

Place cable clips over the other cables, using a different color for each.

<head>
Snap On Covers

<body>

With Monster CleanView™ Cable Management System the edges of the cover pieces are covered. You never see rough edges, and never see spaces between pieces. (Note: See next section if there are any cut pieces in your layout.)

<bullets>

Note: Covers are slightly shorter than Straight base pieces—see diagram.

Covers must go on Straight pieces first, then the Corner(s). Place each Straight piece cover along one edge, then fold down and apply pressure to snap into place.

The cover for the 90-degree Right Angle Connector extends over the edges of the adjoining Straight pieces. Snap into position only after adjoining Straight covers are already in place.

The Joiner/End covers should be snapped into place where Straight pieces join together. They will cover the small gaps between the Straight covers.

The Joiner/End covers may optionally also be used at the very ends of the cable run.

<head>

Cutting The Covers

<body>

Note: This step is only necessary if you cut a base piece in your layout.

<bullets>

Before cutting, first place all full-length cover pieces into position.

A space is required between the covers of Straight pieces. To calculate the length of the cover, subtract 1/2" (13 mm) from the measured length if a Joiner/End cover is used on one side. Subtract 1" (25 mm) if Joiner/End covers will be used on both sides.

Use a pencil to mark the inside of the Straight cover piece(s) at the desired length.

Cut the cover piece(s) using a utility knife or strong scissors.

<head>

Care & Maintenance

<bullets>

Cable covers can be painted with any indoor or outdoor type paint.

Clean exterior with a mild soap or detergent, diluted with water.

Avoid getting internal cables wet.

Avoid getting adhesive wet.

Covers can be removed and reattached for more thorough cleaning.